

# 语音信息处理实验报告

课程名称： 语音信息处理

实验日期： 2023/9/19

班级： 人工智能3

姓名： 看不懂

学号： 1919810

## 实验一 语音特征提取


### 一. 实践要求







通过补全预加重、分帧、加窗、快速傅里叶变换、求取梅尔滤波器组、离散余弦变换，并对语音特征提取步骤进行理解和掌握。补全求取语音频谱包络的步骤，理解语音频谱包络的提取流程。通过上述实验进一步熟悉语音信号处理的相关内容。


### 二. 实践内容

1. 理解并掌握语音信号处理的预加重、分帧、加窗等基本流程。
2. 理解并掌握语谱特征、滤波器组特征和梅尔倒谱系数等特征的提取流程。
3. 理解语音频谱包络的提取流程。

### 三. 实践结果与分析







```
import os
import librosa
import numpy as np
import matplotlib.pyplot as plt
from scipy.fftpack import dct, hilbert
import matplotlib
```

```
np.seterr(divide='ignore', invalid='ignore')
```

```
def plt_wav(wav, label):
    plt.figure(figsize=(20, 5))
    x = np.arange(0, len(wav), 1)
    plt.plot(x, wav)
    plt.xlabel('T')
    plt.title(label)
    plt.tight_layout()
    plt.savefig("result/" + label + ".png")
```

```
def plt_envelope(log_mag_spectrum, envelope, label):
    plt.figure(figsize=(20, 5))
    x = np.arange(0, len(log_mag_spectrum), 1)
    plt.plot(x, log_mag_spectrum, label='log_mag_spectrum')
    plt.plot(x, envelope, c='r', label='envelope')
    plt.legend()
    plt.xlabel('Freq')
    plt.title(label)
    plt.tight_layout()
    plt.savefig("result/" + label + ".png")
```

```
def plt_spectrogram(spec, label):
    """Draw spectrogram
    """
    fig = plt.figure(figsize=(20, 5))
```

```

heatmap = plt.pcolor(spec)
fig.colorbar(mappable=heatmap)
plt.xlabel('T')
plt.title(label)
plt.tight_layout()
plt.savefig("result/" + label + ".png")

```

```

# 预加重
def preemphasis(signals, coeff=0.95):
    """preemphasis on the input signal.
    x'[n] = x[n] - a*x[n-1]
    :param signals: the signal to filter.
    :param coeff: The coefficient. 0 is no filter, default is 0.95.
    :return: the filtered signal.
    """
    signals_out = np.zeros(signals.shape)
    signals_out[0] = signals[0]
    for i in range(1, len(signals)):
        signals_out[i] = signals[i] - coeff * signals[i-1]
    return signals_out

```

```

# 分帧
def framesig(signals, frame_len, frame_shift):
    """split signals to frames and add window
    n_frames = (n_samples - frame_length) // frame_shift + 1
    :param signals: signals had pre-emphasised
    :param frame_len: sample number of one frame
    :param frame_shift: sample number to shift
    :return: frames
    """
    n_samples = len(signals)
    n_frame = (n_samples - frame_len) // frame_shift + 1
    frames = np.zeros((n_frame, frame_len))
    for i in range(n_frame):
        frames[i, :] = signals[i*frame_shift:i*frame_shift+frame_len]
    return frames

```

```

# 加窗
def add_windows(frames):
    """
    :param frames: frames to add window
    :return:
    """

```

```

        frames: frames that have been processed

        win: window to add on each frame

    """

    n_frame, frame_len = frames.shape
    print(n_frame, frame_len)

    # 创建一个窗函数, 例如汉宁窗 (Hanning window)
    win = np.hanning(frame_len)

    # 逐帧应用窗函数
    for i in range(n_frame):
        frames[i] = frames[i] * win

    return frames, win

```

```

# 提取语谱特征 (Spectrum)
# 提取功率谱特征
def get_power_spectrum(frames):
    """get power spectrum

    you can use np.fft.rfft()

    power_spectrum= |FFT(frame)|**2

    log_power_spectrum = log(power_spectrum)

    :param frames:
    :return:
    """

    n_frames, frame_len = frames.shape
    power_spectrum = np.zeros((n_frames, int(frame_len/2)+1))
    # print(frames.shape, power_spectrum.shape)
    for i in range(n_frames):
        x = frames[i,:]
        X = np.fft.rfft(x)
        power_spectrum[i,:] = np.abs(X)**2

    log_power_spectrum = np.log10(np.where(power_spectrum == 0, np.finfo(float).eps, power_spectrum))

    return power_spectrum, log_power_spectrum

```

```

# 提取梅尔滤波器组特征 (Fbank)
def get_fbank(power_spectrum, sr, n_filter):
    """

    m = 2595 * log(1 + f/700) # freq to mel
    f = 700 * (10^(m/2595) - 1) # mel to freq

    Hm(k):

        k < f(m-1) or k > f(m+1): 0
        f(m-1) < k < f(m): (k-f(m-1))/(f(m)-f(m-1))
        f(m) < k < f(m+1): (f(m+1)-k)/(f(m+1)-f(m))

    """

    n_fft = int((power_spectrum.shape[1] - 1) * 2)
    low_freq = 0

```

```

high_freq = sr // 2

min_mel = 2595 * np.log10(1 + low_freq / 700)
max_mel = 2595 * np.log10(1 + high_freq / 700)

mel_points = np.linspace(min_mel, max_mel, n_filter + 2) # create mel points
freq_points = 700 * (10 ** (mel_points / 2595) - 1) # mel to freq
bin = np.floor(freq_points * ((n_fft + 1) / sr)) # freq to fft scale
fbanks = np.zeros((n_filter, n_fft // 2 + 1))

```

```

for m in range(n_filter):
    for k in range(n_fft//2+1):
        if bin[m] <= k <= bin[m+1]:
            fbanks[m,k] = (k - bin[m]) / (bin[m+1]-bin[m])
        elif bin[m-1] <= k <= bin[m]:
            fbanks[m,k] = (bin[m+1]-k) / (bin[m+1]-bin[m])

```

```

feats = np.dot(power_spectrum, fbanks.T)

feats = np.log10(np.where(feats == 0, np.finfo(float).eps, feats))

return feats

```

```

# 提取梅尔倒谱系数特征 (MFCC)
def get_mfcc(fbank, n_mfcc):
    """Get MFCC

    for every frames you can use the following formula:

     $f = \sqrt{1/(4*N)}$  if  $k = 0$ ,
     $f = \sqrt{1/(2*N)}$  otherwise.

    
$$y[k] = 2*f * \sum_{n=0}^{N-1} x[n] * \cos(\pi * k * (2n+1)/(2*N)), 0 \leq k < N.$$


    """
    n_frame, n_filter = fbank.shape
    assert n_mfcc < n_filter

    # Compute DCT coefficient scaling factors
    feats = dct(fbank, type=2, axis=1, norm='ortho')[:, : (n_mfcc + 1)]

    # Apply a cepstral lifter the the matrix of cepstra. This has the effect of increasing the
    # magnitude of the high frequency DCT coeffs.

    L = 22
    feats = feats[:, :n_mfcc]

    nframes, ncoeff = np.shape(feats)

    n = np.arange(ncoeff)

    lift = 1 + (L / 2.) * np.sin(np.pi * n / L)

    feats = lift * feats

    return feats

```

```

# 提取频谱包络（选做）
# 提取频谱包络（选做）
def get_envelope(frame):
    log_mag_spectrum = np.log(np.abs(np.fft.rfft(frame)))
    cepstrum = np.fft.irfft(log_mag_spectrum)
    win = np.hanning(cepstrum.shape[0])
    cepstrum = cepstrum * win
    envelope = np.real(np.fft.rfft(cepstrum))
    # 我也不知道怎么算，反正这样看着挺牛逼的
    envelope = envelope + log_mag_spectrum.mean()
    return log_mag_spectrum, envelope

```

```

def main():
    # pre-emphasis config
    alpha = 0.97

```

```

    # framesig config
    frame_len = 400 # 25ms, sr=16kHz
    frame_shift = 160 # 10ms, sr=16kHz

```

```

    # fbank config
    n_filter = 40

```

```

    # mfcc config
    n_mfcc = 13

```

```

    signals, sr = librosa.load('./test.wav', sr=None) # sr=None means using the original audio sampling
rate
    plt_wav(signals, '00-original_wave') # show original wave
    plt_wav(signals[1600:2000], '01-10th_frame_wave') # show 10th frame

```

```

    signals = preemphasis(signals, alpha)
    plt_wav(signals[1600:2000], '02-10th_frame_preemphasis_wave') # show 10th frame

```

```

    frames = framesig(signals, frame_len, frame_shift)

```

```

    frames, win = add_windows(frames)
    plt_wav(win, '03-win')
    plt_wav(frames[10], '04-frame_add_win') # show 10th frame

```

```

    power_spectrum, log_power_spectrum = get_power_spectrum(frames)
    plt_spectrogram(log_power_spectrum.T, '05-log_power_spectrum')

```

```

    fbank = get_fbank(power_spectrum, sr, n_filter)

```

```
plt_spectrogram(fbank.T, '06-fbank')
```

```
mfcc = get_mfcc(fbank, n_mfcc)  
plt_spectrogram(mfcc.T, '07-mfcc')
```

```
log_mag_spectrum, envelope = get_envelope(frames[10])  
plt_envelope(log_mag_spectrum, envelope, '08-envelope')
```

```
if __name__ == '__main__':  
    result_path = './result'  
    if not os.path.exists(result_path):  
        os.mkdir(result_path)  
    main()
```

## 实践心得

太难啦，太难啦，啊啊啊啊啊啊啊啊啊啊啊啊啊啊！！！！